
Undergraduate Certificate in Advanced Combustion Engineering

Emissions Control Technologies

Acid Gas Scrubber

Related terms: flue gas desulfurization, wet scrubber, limestone slurry, spray tower

Definition: A wet-scrubbing system that removes acidic gases such as SO₂ and HCl from combustion exhaust by contacting the flue gas with a liquid absorbent. The absorbent reacts chemically to form neutral salts, which are collected as a sludge.

Example: A coal-fired power plant uses a limestone-based acid gas scrubber to achieve >95 % removal of SO₂.

Practical application: Widely employed in utility boilers, petroleum refineries, and waste-to-energy facilities to meet sulfur emissions limits.

Challenges: High water consumption, disposal of spent sludge, corrosion of equipment, and the need for precise pH control to maintain reaction efficiency.

Activated Carbon

Related terms: adsorption, mercury control, porous media, regeneration

Definition: A form of carbon processed to have a high surface area and porosity, enabling it to adsorb volatile organic compounds (VOCs), mercury, and other trace pollutants from flue gases.

Example: An activated carbon injection system captures elemental mercury in the flue gas of a municipal solid-waste incinerator, achieving removal efficiencies of 80–90 %.

Practical application: Used in conjunction with baghouses or electrostatic precipitators for post-combustion pollutant control.

Challenges: Limited capacity for high-temperature streams, the need for periodic replacement or regeneration, and potential for carbon dust release if not properly managed.

Air-Staged Combustion

Related terms: staged combustion, reburning, NO_x reduction, oxygen-enrichment

Definition: A combustion strategy where the air supply is divided into primary and secondary stages, creating a fuel-rich zone followed by a lean zone, which suppresses peak flame temperatures and consequently reduces thermal NO_x formation.

Example: A natural-gas boiler employing air-staged combustion reduces NO_x emissions from 150 ppm to below 30 ppm without additional post-combustion controls.

Practical application: Common in industrial furnaces and boiler designs where NO_x limits are stringent.

Challenges: Requires precise control of airflow distribution, may affect combustion stability, and can lead to increased CO emissions if the fuel-rich zone is not properly balanced.

Ammonia Slip

Related terms: selective catalytic reduction, SCR, ammonia slip catalyst, NO_x control

Definition: The unreacted ammonia that passes through an SCR system and is emitted with the flue gas, potentially forming secondary pollutants such as ammonium salts.

Example: In a coal-fired power plant, ammonia slip is monitored and kept below 10ppm by adjusting the urea injection rate and installing an ammonia slip catalyst downstream of the SCR reactor.

Practical application: Monitoring and controlling ammonia slip is essential to avoid downstream fouling and to comply with ambient air quality standards.

Challenges: Balancing sufficient ammonia for NO_x reduction while minimizing slip, dealing with variability in flue-gas composition, and ensuring catalyst durability.

Atmospheric Plasma Reactor

Related terms: plasma oxidation, non-thermal plasma, VOC destruction, dielectric barrier discharge

Definition: A device that generates a high-energy plasma field to oxidize and decompose pollutants such as VOCs, NO_x, and CO at relatively low temperatures, leveraging energetic electrons rather than bulk gas heating.

Example: A pilot-scale atmospheric plasma reactor treats the exhaust of a metal-working shop, achieving >99% VOC destruction with a power input of 5 kW.

Practical application: Offers a compact, rapid-response solution for intermittent or low-volume emission sources.

Challenges: High electrical energy consumption, electrode wear, and limited scalability for large-scale industrial applications.

Baghouse (Fabric Filter)

Related terms: particulate control, dust collector, filter cake, pulse-jet cleaning

Definition: A filtration device that captures particulate matter from flue gases by passing the gas through fabric filter media, where particles accumulate as a filter cake and are periodically removed by a cleaning pulse.

Example: A cement plant uses a baghouse to remove >99% of PM₁₀, meeting the strictest particulate standards.

Practical application: Serves as a primary particulate control device and can be combined with sorbent injection for acid gas removal.

Challenges: Filter media wear, potential for filter rupture under high-temperature conditions, and the need for regular maintenance to prevent pressure drop increases.

Baseline Emissions

Related terms: emissions inventory, regulatory baseline, performance benchmarking, stack testing

Definition: The measured or estimated emissions levels of a facility before the implementation of control technologies, used as a reference point for evaluating reduction effectiveness.

Example: Baseline NO_x emissions of 200ppm are established for a turbine before installing a low-NO_x burner.

Practical application: Provides a basis for compliance reporting, permits, and the calculation of emission credits.

Challenges: Accurate baseline determination requires comprehensive testing, accounting for operational variability, and may be subject to regulatory revisions.

Carbon Capture and Storage (CCS)

Related terms: CO₂ sequestration, post-combustion capture, amine scrubbing, geological storage

Definition: A suite of technologies that capture carbon dioxide from flue gases, compress it, transport it, and permanently store it in geological formations to mitigate climate change.

Example: A natural-gas combined-cycle plant captures 90 % of its CO₂ using a monoethanolamine (MEA) solvent and injects it into a depleted oil reservoir.

Practical application: Enables continued use of fossil fuels while reducing net greenhouse-gas emissions.

Challenges: High capital and operating costs, energy penalty (typically 10–15 % of plant output), solvent degradation, and public acceptance of storage sites.

Catalytic Oxidation

Related terms: catalyst, oxidation reactor, VOC abatement, temperature window

Definition: A process where a catalyst promotes the oxidation of pollutants (e.g., VOCs, CO) to CO₂ and H₂O at temperatures lower than would be required for thermal oxidation alone.

Example: A catalytic oxidizer reduces VOC concentrations from 500 ppm to Combustion Modification

Related terms: low-NO_x burners, staged combustion, flue-gas recirculation, flame temperature control

Definition: Engineering adjustments to the combustion process that aim to reduce pollutant formation at the source, primarily targeting NO_x, CO, and unburned hydrocarbons.

Example: Implementing flue-gas recirculation (FGR) in a boiler reduces peak flame temperature, achieving a 60 % NO_x reduction.

Practical application: Often the first line of defense in emission control strategies, complementing downstream technologies.

Challenges: Potential loss of combustion efficiency, increased CO emissions if not properly tuned, and the need for sophisticated control systems.

Diffusion Flame

Related terms: laminar flame, premixed flame, flame speed, flame stability

Definition: A flame where the fuel and oxidizer mix by diffusion rather than being premixed, leading to a characteristic shape and temperature profile that influences pollutant formation.

Example: A diffusion flame in a gas turbine combustor exhibits higher NO_x production compared to a premixed flame due to elevated local temperatures.

Practical application: Understanding diffusion flame behavior assists in designing burners that minimize NO_x while maintaining stable combustion.

Challenges: Controlling flame anchoring and preventing flashback in high-temperature environments.

Dry Sorbent Injection (DSI)

Related terms: calcium carbonate, sodium bicarbonate, particulate control, flue-gas desulfurization

Definition: A technique where dry alkaline sorbent powders are injected into the flue gas stream to react with acidic gases (SO_2 , HCl) and form solid salts that are captured by downstream particulate control devices.

Example: An industrial boiler injects calcium carbonate at a rate of 2 lb/10⁶ Btu, achieving 70 % SO_2 removal.

Practical application: Offers a low-cost, retrofit-friendly option for acid gas reduction without the need for liquid handling systems.

Challenges: Sorbent handling and storage, increased particulate loading on downstream filters, and limited removal efficiency for high sulfur-content fuels.

Electrostatic Precipitator (ESP)

Related terms: particulate removal, corona discharge, collection plates, particle charging

Definition: An electrostatic device that charges particles in the flue gas and collects them on oppositely charged plates, allowing for continuous removal of fine particulates.

Example: An ESP in a steel mill captures >99 % of sub-micron particles, reducing $\text{PM}_{2.5}$ emissions to regulatory limits.

Practical application: Provides high-efficiency particulate control for high-temperature, high-volume gas streams.

Challenges: Plate fouling, reduced efficiency with low-resistivity particles, and the need for periodic re-conditioning to maintain performance.

Flame Temperature

Related terms: adiabatic flame temperature, NO_x formation, thermal NO_x , temperature control

Definition: The peak temperature reached within the combustion zone, a primary driver of thermal NO_x production according to the Zeldovich mechanism.

Example: Reducing flame temperature from 2100 K to 1800 K in a furnace lowers NO_x emissions by approximately 50 %.

Practical application: Temperature management is central to NO_x mitigation strategies such as staged combustion and flue-gas recirculation.

Challenges: Maintaining combustion efficiency while lowering temperature, and avoiding excessive CO or unburned hydrocarbon formation.

Flue-Gas Desulfurization (FGD)

Related terms: wet scrubber, limestone slurry, sulfur dioxide removal, by-product gypsum

Definition: A set of processes that remove SO_2 from flue gases, typically using a wet scrubbing system where a limestone slurry reacts with SO_2 to form calcium sulfite, which is later oxidized to gypsum.

Example: A utility plant's FGD system removes 95 % of SO_2 , producing marketable gypsum for the construction industry.

Practical application: Essential for compliance with sulfur emission regulations on coal-fired power plants.

Challenges: High water usage, disposal of waste sludge, corrosion, and the need for continuous monitoring

of slurry chemistry.

Fuel-Rich Zone

Related terms: staged combustion, reburning, NO_x reduction, reducing atmosphere

Definition: The region in a combustion system where the fuel-to-air ratio exceeds stoichiometric, creating a reducing environment that can help convert NO_x to N₂ during subsequent stages.

Example: In a reburning system, a fuel-rich zone is created by injecting natural gas downstream of the primary burner, achieving up to 60% NO_x reduction.

Practical application: Used in conjunction with reburning or selective non-catalytic reduction (SNCR) to enhance nitrogen oxide control.

Challenges: Managing CO emissions, ensuring stable flame, and avoiding flame blow-off.

Gas-Phase Catalysis

Related terms: homogeneous catalysis, SCR, NO_x reduction, catalyst promoter

Definition: Catalytic reactions that occur in the gaseous phase, often involving transition-metal compounds that facilitate pollutant conversion without a solid support.

Example: A homogeneous SCR system using ammonia and a copper-based catalyst reduces NO_x at temperatures between 250–350 °C.

Practical application: Offers flexibility in reactor design and can be integrated into compact emission control units.

Challenges: Catalyst recovery, potential for catalyst deactivation, and handling of toxic or corrosive catalyst species.

Halogenated Hydrocarbon

Related terms: chlorinated VOCs, HCl emissions, flame retardants, pollutant source

Definition: Organic compounds containing halogen atoms (Cl, Br, F) that can be released during combustion, contributing to corrosive acid formation and ozone depletion.

Example: Burning PVC waste releases HCl, which can corrode downstream equipment if not properly scrubbed.

Practical application: Identifying halogenated hydrocarbon emissions helps in selecting appropriate scrubber chemistries (e.g., alkaline sorbents).

Challenges: Accurate detection, managing corrosivity, and ensuring compliance with hazardous air pollutant regulations.

High-Temperature Oxidation

Related terms: thermal oxidation, incineration, VOC destruction, temperature threshold

Definition: A method of destroying organic pollutants by heating the flue gas to temperatures typically above 850 °C, where oxidation reactions proceed rapidly, converting pollutants to CO₂ and H₂O.

Example: A hazardous waste incinerator operates at 950 °C, achieving >99.9% VOC destruction efficiency.

Practical application: Used for the treatment of high-strength waste streams where low-temperature technologies are insufficient.

Challenges: High energy consumption, formation of nitrogen oxides at elevated temperatures, and the need for robust materials to withstand thermal stress.

Hydrocarbon (HC) Emissions

Related terms: unburned hydrocarbons, VOCs, incomplete combustion, flame quenching

Definition: Emissions consisting of organic compounds that have not been fully oxidized during combustion, often indicating poor flame stability or insufficient residence time.

Example: A gas turbine operating at low load may emit 10 ppm of unburned HC, exceeding the permitted limit.

Practical application: Monitoring HC emissions helps optimize combustion parameters and detect fuel-rich conditions.

Challenges: Balancing low NO_x operation with HC control, and ensuring reliable detection in the presence of other pollutants.

Inert Gas Recirculation (IGR)

Related terms: flue-gas recirculation, nitrogen dilution, NO_x control, combustion stability

Definition: The process of recirculating a portion of the exhaust gas back into the combustion zone to lower peak flame temperatures and reduce thermal NO_x formation.

Example: An industrial furnace recirculates 20 % of its flue gas, achieving a 45 % reduction in NO_x emissions.

Practical application: Provides a flexible method for NO_x control that can be adjusted in real time.

Challenges: Potential increase in CO emissions, need for robust mixing equipment, and impact on furnace heat transfer.

Low-NO_x Burner

Related terms: staged combustion, flame temperature control, NO_x reduction, fuel staging

Definition: A burner design that incorporates air staging, fuel staging, or swirl to limit peak flame temperatures and reduce the formation of thermal NO_x.

Example: A low-NO_x natural-gas burner installed in a boiler reduces NO_x from 300 ppm to 30 ppm without additional downstream controls.

Practical application: Commonly used in boiler retrofits and new installations where NO_x limits are stringent.

Challenges: Maintaining combustion efficiency, avoiding excessive CO formation, and ensuring reliable operation across a range of loads.

Mercury (Hg) Emission Control

Related terms: activated carbon injection, oxidation catalysts, elemental mercury, mercury speciation

Definition: Technologies aimed at capturing and converting mercury species in flue gases, typically involving oxidation of elemental mercury to oxidized forms followed by adsorption onto sorbents.

Example: A coal plant injects activated carbon downstream of an oxidation catalyst, achieving 85 % mercury removal.

Practical application: Essential for compliance with mercury emission regulations, especially for coal-fired units.

Challenges: Variability in mercury speciation, sorbent cost, and the need for precise control of catalyst temperature and flue-gas composition.

Non-Thermal Plasma

Related terms: dielectric barrier discharge, plasma oxidation, VOC abatement, low-temperature plasma

Definition: A plasma technology that generates energetic electrons at near-ambient gas temperatures, enabling the oxidation of pollutants without raising bulk gas temperature.

Example: A non-thermal plasma reactor treats diesel exhaust, reducing NO_x by 40% with a modest power input.

Practical application: Suitable for mobile sources and intermittent emission streams where thermal methods are impractical.

Challenges: Energy efficiency, electrode degradation, and scale-up to industrial flow rates.

Oxidation Catalyst

Related terms: catalyst support, noble metals, VOC oxidation, catalyst deactivation

Definition: A solid catalyst, often based on platinum or palladium, that facilitates the oxidation of VOCs, CO, and other reducible gases at moderate temperatures.

Example: An oxidation catalyst placed before a baghouse reduces VOC concentrations from 200 ppm to Particulate Matter (PM)

Related terms: PM_{2.5}, PM₁₀, aerosol, filter cake, coarse particles

Definition: Solid or liquid particles suspended in the flue gas, ranging from sub-micron to several micrometers in diameter, which can impact human health and visibility.

Example: A cement kiln emits 0.1 g/Nm³ of PM_{2.5}, requiring control to meet stringent local air quality standards.

Practical application: Measurement and control of PM are central to compliance with particulate emission limits.

Challenges: Capturing ultrafine particles, handling ash disposal, and maintaining filter efficiency under variable operating conditions.

Passive NO_x Control

Related terms: low-NO_x burners, fuel staging, natural gas dilution, temperature management

Definition: Strategies that reduce NO_x formation directly within the combustion zone without the need for additional downstream treatment equipment.

Example: Implementing fuel staging in a boiler reduces NO_x emissions by 30% without installing an SCR system.

Practical application: Cost-effective initial step in emission reduction plans, especially for new installations.

Challenges: Limited reduction potential compared to active controls, and the need for precise combustion tuning.

Plasma-Assisted Combustion

Related terms: plasma ignition, flame stabilization, low-temperature combustion, electric field enhancement

Definition: The use of plasma discharges to generate radicals and ions that promote combustion, allowing stable flame operation at lean mixtures and lower temperatures.

Example: A plasma-assisted burner operates at an equivalence ratio of 0.6, achieving stable combustion with reduced NO_x emissions.

Practical application: Enables ultra-lean combustion regimes for high-efficiency, low-emission burners.

Challenges: Power supply integration, electrode erosion, and ensuring uniform plasma distribution.

Post-Combustion NO_x Reduction

Related terms: SCR, SNCR, selective catalytic reduction, non-catalytic reduction

Definition: Technologies applied to the flue gas after combustion to convert NO_x to nitrogen and water, typically using reductants such as ammonia or urea.

Example: A selective catalytic reduction (SCR) system installed on a coal-fired boiler reduces NO_x from 500 ppm to below 30 ppm.

Practical application: Widely adopted in power generation, industrial boilers, and marine engines.

Challenges: Reductant handling, catalyst poisoning, temperature control, and ammonia slip management.

Reburning

Related terms: fuel-rich zone, NO_x reduction, staged combustion, secondary fuel injection

Definition: A NO_x control technique where a secondary fuel (often natural gas) is injected downstream of the primary combustion zone to create a fuel-rich environment that reduces NO_x to N₂.

Example: Reburning in a coal-fired boiler achieves a 40% reduction in NO_x while maintaining overall combustion efficiency.

Practical application: Provides a cost-effective alternative to SCR for moderate NO_x reductions.

Challenges: Managing increased CO emissions, ensuring thorough mixing, and controlling the temperature profile to avoid excess unburned carbon.

Selective Catalytic Reduction (SCR)

Related terms: ammonia injection, catalyst, NO_x reduction, urea, ammonia slip

Definition: A catalytic process where ammonia (or urea) reacts with NO_x over a catalyst at temperatures typically between 300–400 °C, converting NO_x to N₂ and H₂O with high efficiency.

Example: An SCR unit on a diesel locomotive reduces NO_x emissions by 90% while maintaining engine performance.

Practical application: The most effective post-combustion NO_x control technology for large stationary and mobile sources.

Challenges: Catalyst cost, ammonia slip, need for precise temperature control, and sensitivity to sulfur and particulate fouling.

Selective Non-Catalytic Reduction (SNCR)

Related terms: ammonia injection, high-temperature reduction, NO_x reduction, thermal NO_x

Definition: A non-catalytic process where ammonia or urea is injected into the flue gas at temperatures of 850–1100 °C, causing direct reduction of NO_x to N₂ without a catalyst.

Example: An SNCR system installed in a cement kiln reduces NO_x by 30 % with a simple injection system.

Practical application: Offers a lower-cost alternative to SCR where catalyst installation is impractical.

Challenges: Narrow temperature window, lower reduction efficiency, and the risk of ammonia slip if the reaction is incomplete.

Soot Oxidation

Related terms: carbon burnout, oxidation catalyst, high-temperature oxidation, particulate removal

Definition: The process of converting carbonaceous particles (soot) in the flue gas to CO₂, often using elevated temperatures or catalytic aids to ensure complete burnout.

Example: Adding a copper-based oxidation catalyst to a furnace exhaust stream increases soot oxidation efficiency from 70 % to 95 %.

Practical application: Improves the performance of particulate control devices and reduces visible emissions.

Challenges: Catalyst deactivation, temperature management, and handling of the resulting CO₂ stream.

Steam Injection

Related terms: flue-gas recirculation, temperature control, NO_x reduction, combustion dilution

Definition: The injection of steam into the combustion zone to increase the mass flow, lower flame temperature, and dilute the oxygen concentration, thereby reducing NO_x formation.

Example: A gas turbine employs steam injection to achieve a 20 % reduction in NO_x while maintaining power output.

Practical application: Often used in combined-cycle plants where waste steam is readily available.

Challenges: Additional water consumption, potential for increased corrosion, and the need for precise control to avoid flame instability.

Sulfur Dioxide (SO₂) Removal

Related terms: acid gas scrubbing, limestone slurry, dry sorbent injection, gypsum production

Definition: Technologies designed to capture and convert SO₂ from flue gases, thereby preventing acid rain and complying with sulfur emission limits.

Example: A wet FGD system removes 98 % of SO₂ from a coal plant's flue gas, producing gypsum for use in wallboard manufacturing.

Practical application: Integral to coal-fired power plant emission control trains.

Challenges: High water usage, disposal of waste by-products, and maintaining high removal efficiency under variable load conditions.

Thermal NO_x

Related terms: Zeldovich mechanism, flame temperature, high-temperature oxidation, NO_x formation

Definition: NO_x generated from the oxidation of atmospheric nitrogen at high temperatures (typically >1800 K) during combustion, following the kinetic pathways described by Zeldovich.

Example: In a furnace operating at 2100 K, thermal NO_x may account for 80 % of total NO_x emissions.

Practical application: Understanding thermal NO_x guides the design of temperature-control strategies such as staged combustion.

Challenges: Reducing flame temperature without sacrificing combustion efficiency or increasing CO emissions.

Ultra-Low-NO_x (ULN) Burner

Related terms: advanced combustion, multi-stage staging, flame shaping, NO_x VOC (Volatile Organic Compound) Destruction

Related terms: catalytic oxidizer, thermal oxidizer, plasma oxidation, destruction removal efficiency (DRE)

Definition: The removal or conversion of VOCs from exhaust streams to CO₂ and H₂O, typically measured by destruction removal efficiency.

Example: A catalytic oxidizer achieves a DRE of 99.5 % for a mixture of aromatic VOCs at 300 °C.

Practical application: Critical for compliance with hazardous air pollutant (HAP) regulations in solvent-intensive industries.

Challenges: Catalyst poisoning, high inlet VOC concentrations, and the need for reliable temperature control to avoid incomplete oxidation.

Water-Cooled Scrubber

Related terms: wet scrubber, heat recovery, acid gas removal, limestone slurry

Definition: A scrubber design where the absorbent liquid is cooled by water, allowing efficient removal of acidic gases while minimizing the temperature rise of the flue gas.

Example: A water-cooled FGD unit reduces the temperature of the flue gas by 30 °C, improving downstream heat-exchange efficiency.

Practical application: Used where downstream temperature constraints are critical, such as in combined-cycle plants.

Challenges: Managing water usage, preventing scaling on heat-exchange surfaces, and ensuring adequate residence time for chemical reactions.

Zeldovich Mechanism

Related terms: thermal NO_x, high-temperature chemistry, nitrogen oxidation, reaction kinetics

Definition: The set of elementary reactions describing the formation of NO_x from atmospheric nitrogen and oxygen at high temperatures, primarily responsible for thermal NO_x generation in combustion.

Example: The rate of NO formation increases exponentially with temperature according to the Zeldovich mechanism, emphasizing the importance of flame-temperature control.

Practical application: Forms the theoretical basis for NO_x mitigation strategies such as flame-temperature reduction and staged combustion.

Challenges: Accurately modeling the mechanism in CFD simulations, especially under transient operating conditions.